

## ADVANTAGES

FAST AND EASY TO USE - JUST BRUSH IN

NO MIXING  
REQUIRED

NO SPECIAL TOOLS  
REQUIRED

SETS HARD -  
DOES NOT WASH OUT

CAN BE APPLIED  
IN THE WET

IMPENETRABLE  
TO WEEDS

WATERPERMEABLE



# KNOW-HOW FROM SITE TO SHELF



© Sika SERVICES AG / REFURBISHMENT / DMOL / Sika® FastFix-132 PaveFix / 08.2016 / 10.66431



SCAN TO VIEW  
PRODUCT VIDEO

### Sika Services AG

Refurbishment  
CH-8048 Zurich  
Switzerland  
Phone +41 58 436 23 68  
Fax +41 58 436 23 77  
[www.sika.com](http://www.sika.com)

Our most current General Sales Conditions shall apply.  
Please consult the most current local Product Data Sheet prior to any use.

## Sika® FastFix-132 PaveFix SELF-SETTING JOINTING COMPOUND FOR PAVING, PATHS & PATIOS



# Sika® FastFix-132 PaveFix

## PERFECT JOINTING FOR GARDENS, PATIOS AND TERRACES

Sika® FastFix-132 PaveFix is a ready to use, self-setting compound that gives perfect jointing for paving joints over 5 mm wide and at least 25 mm deep.

### CAN BE USED ON:

- Flagstone
- Stone setts
- Slabs
- Cobbles
- Paving blocks
- Indian sandstone

### PRODUCT INFORMATION

Pack size: 15 kg bucket

Colors:

- Buff
- Grey



Please note that this is not the exact color.

Coverage approximately 12.5 m<sup>2</sup> 450 x 450 mm paving  
(6 x 25 mm joints)



## 5 STEPS TO A PERFECT FINISH ...



■ **Step 1:** Ensure all joints to be pointed with Sika® FastFix-132 PaveFix have a minimum full depth width of 5 mm and are at least 25 mm deep. Recommend wetting paving lightly before application, but joints should be free of standing water, dirt, debris or weeds. Ensure the paving bedding is well drained.




■ **Step 2:** Remove Sika® FastFix-132 PaveFix from the packaging and cut the bag. Once punctured or opened the material must be used within 1 hour.



■ **Step 3:** Use Sika® FastFix-132 PaveFix in small manageable amounts. Avoid spreading over a large area before application. Ensure material is loose by raking through. Do not try to break up and use any small set lumps. Do not add any extra sand.



■ **Step 4:** Using a soft broom, or hand brush for smaller areas, work Sika® FastFix-132 PaveFix into the joints. Make sure each joint is completely filled and the material well compressed.



■ **Step 5:** Sika® FastFix-132 PaveFix will start to set in 6 to 12 hours above 15°C in dry conditions. Allow up to 4 days for full set in temperatures between 4°C and 15°C. Contact with rain or moisture can slow the final set.